MARBLE RESTORER

MARBLE RESTORATION KIT



MARBLE RESTORATION KIT: removes acid stains and restores polish on small marble and travertine surfaces and on agglomerates.



COVERAGE

COVERAGE (1 KIT):

HIGH COVERAGE: kit for restoring surfaces (1.5 m²) with up to 30 damaged areas measuring 6 to 7 cm in diameter.

The coverage values are purely indicative and depend on the state of wear of the material.

5 m²

Packaging

Boxes of 4.



POLISHED MARBLE, POLISHED MARBLE AGGLOMERATES

THE KIT CONTAINS

- · FILA MARBLEONE yellow metal pad
- · FILA MARBLETWO white resin-coated pad
- · FILA MARBLETHREE blue resin-coated pad
- FILA MARBLESPONGE white polishing sponge
- FILA MARBLESHINE, marble polish 200 ml
- FILA FORMULA MARMO, marble polish 250 ml
- Protective gloves

WHAT IT'S FOR

- · Restoring small marble, travertine or polished limestone surfaces, that have been attacked by acidic substances or weather conditions
- · Ideal for restoring bathroom or kitchen worktops, tables, steps, doorsteps, window sills
- · It also eliminates dullness due to wear and tear
- · Effective on marble surfaces and on all polished limestones
- · Effective on marble-concrete agglomerates (terrazzo), marble-resin agglomerates with polished finish

HOW TO USE IT

PHASE 1: SMOOTH

Wet the surface with water and rub first with the yellow MARBLE ONE pad, then using the white MARBLE TWO pad and, lastly, with the blue MARBLE THREE pad, extending the work surface slightly. Dry with a cloth or paper towels.

• PHASE 2: POLISH

Apply MARBLE SHINE and polish using the MARBLE SPONGE. Thoroughly remove any residues using a damp sponge and dry with a soft cloth.

These are very generic instructions; for specific information please carefully read the booklet contained in the box.

WARNINGS

Keep out of reach of children.
Do not disperse into the environment after use.

TEMPERATURES

Storage temperature: from 5° to 30° C. The product should be applied to materials with temperature between 5° and 30°C.

Caution:

Some marble types, naturally resistant to acids, like "verde alpi" marble, cannot be polished with this treatment system.