

WATER-REPELLENT PROTECTION

UNPOLISHED MARBLE AND GRANITE, UNPOLISHED STONE AND AGGLOMERATES, CONCRETE, MANUFACTURED STONE



The **SOLVENT-BORNE TECHNOLOGY**, developed in the FILA research laboratories, is characterised by protective agents capable of making the material highly water-repellent and resistant to the most diverse weather conditions and UV rays.



COVERAGE

| APPROXIMATE COVERAGE (1 litre): | |
|---------------------------------|----------------------|
| Natural stone | 10/20 m ² |
| Concrete | 5 m ² |

“Coverage shown is for guidance purposes only and refers to single coats”

Packaging

1 litre: boxes of 12.
5 litres: boxes of 4.

WARNINGS

- Keep out of reach of children.
- Do not disperse into the environment after use.
- Does not protect against acidic aggression.
- The use of a single-disc cleaning machine is permitted only if it is perfectly undamaged.
- Outdoor flooring must be properly laid before being treated and must satisfy all specific requirements, including: adequate sloping, properly executed expansion joints, perfect insulation from underlying ground, proven compatibility with sub-zero temperatures.

TEMPERATURES

Storage temperature: from 0°C to 30°C
The product should be applied to materials with temperature between 5° and 30°C.

WHAT IT'S FOR

- Protects outdoor floors from water and damp
- Makes walls and coverings water-repellent
- Ideal for concrete
- Protects grout joints
- Protects against deterioration due to weather conditions

ADVANTAGES

- It provides a breathable, lasting and renewable protection
- Does not affect the material's natural look
- Does not yellow with ageing or with any environmental condition
- High penetration depth
- Provides high coverage
- Prevents moss and mould formation
- It protects against efflorescence
- An **A+** classified product in accordance with the French VOC regulation

HOW TO USE IT

No dilution required: ready to use.

Application: Apply **HYDROREP** on a clean and dry surface using a brush or other application method in a regular manner, with two coats with an 8-hour interval in between. In case of poorly absorbent stone surfaces (e.g. slate), a single coat of the product is sufficient.

To complete the cycle with an oil-repellent protection: apply the **FOB XTREME** stain-proofing protective agent instead of the second coat of **HYDROREP**. The surface can be walked on after just 8 hours. The water-repellent effect starts after 24 hours.

FOR PROFESSIONAL USE ONLY: spray the product (airless system) on vertical surfaces until they are saturated and use appropriate PPE, as specified in the safety information sheet.

Caution:

*On natural stone carry out a patch test on a small surface area to check for any changes in colour.
Do not apply the product externally if rain is forecast.
Does not protect against acidic aggression.*