

## ECO-COMPATIBLE WATER-REPELLENT PROTECTION

UNPOLISHED STONE AND AGGLOMERATES,  
CONCRETE, TERRACOTTA, EXPOSED BRICKS,  
QUARRY TILES, PLASTER, TUFF



Anti-fouling tested in accordance with the UNI EN ISO 846:1999 standard. The formulation limits the deterioration of the surface when exposed to organic decay.



### COVERAGE

#### COVERAGE (1 litre):

Terracotta, exposed brick walls,  
quarry tiles, stone, plaster **10-20 m<sup>2</sup>**

Concrete **8-10 m<sup>2</sup>**

Coverage shown is indicative and refers to single coats

#### Packaging

1 litre: boxes of 12.

5 litres: boxes of 4.

#### WARNINGS

- Keep out of reach of children.
- Do not disperse into the environment after use.
- Outdoor flooring must be properly laid before being treated and must satisfy all the specific requirements, including: adequate sloping, properly executed expansion joints, perfect isolation from the underlying ground, proven compatibility with sub-zero temperatures. It does not protect marble and limestone from acid.

#### TEMPERATURES

Storage temperature: from 5° to 30° C.

This product must be applied to surfaces with temperature between 10°C and 30°C.

### WHAT IT'S FOR

- Water-repellent with natural finish.
- Deeply penetrates the material while allowing the surface to breathe.
- Hampers the build-up of algae, moulds and lichen.
- Protects the surface against deterioration caused by weathering.

### ADVANTAGES

- Anti-fouling barrier certified by tests conducted in conformity to the UNI EN ISO 846: 1999 method
- Ideal for protecting exterior walls
- Resists UV radiation
- Does not alter terracotta frost resistance
- It protects against efflorescence
- Can be applied to surfaces with residual moisture: drastically reduced application times
- The treatment preserves the material's level of breathability above 90%
- An **A+** classified product in accordance with the French VOC regulation

### HOW TO USE IT

**No dilution required:** ready to use.

**Application:** Make sure that the surface is dry and clean, then apply the product by impregnating the material until it is saturated, using a brush or other application method. Dab any excess product with a clean cloth before it dries (roughly 10-15 minutes). The surface can be walked on after 4 hours. The water-repellent effect starts after 24 hours.

**CLEANING OF TOOLS:** clean with water after use.

**FOR PROFESSIONAL USE ONLY:** to apply the product with an airless system or other spray applicators, use the appropriate PPE, as indicated in the safety data sheet.

#### Caution:

*Since there are so many different materials, before applying the product we recommend testing it on a small area of the surface to check for any colour changes. Avoid surface pooling.*

*Do not apply the product outdoors if rain is forecast. Any stubborn product residues can also be removed when dry, by using **FASEZERO** diluted 1:10 and a white disc.*

*Avoid applying on surfaces with condensation and under direct sunlight. Does not protect against acid aggression.*